



PV - PARTICLE VAC 120V

PACKING LIST

- 1 - PV - Particle Vac unit
- 1 - Power Cord
- 1 - Adapter 1½" Accessory x 2½" Hose End (VMC-1036)
- 1 - 2½" x 6' Hose (VMC-1023)

IMPORTANT SERVICE INFORMATION:
SAVE SHIPPING BOX AND FOAM FOR FUTURE SERVICE.
SHIPPING WITHOUT PROPER FOAM MAY CAUSE DAMAGE TO UNIT.

ASSEMBLY INSTRUCTIONS

1. Remove the unit and other parts from the box and check against the packing list.
2. Plug the removable power cord into the socket labeled "POWER" on the top of the PV - Particle Vac. Plug the other end into a standard wall socket. Try the unit by turning the switch to the "ON" position. Use the speed control knob to select preferred speed. The speed selected will depend on the job being performed and the user's preference.
3. The vacuum hose supplied slips onto the vacuum connection on top of the unit and the other end connects to the collection device desired. The ideal location for the PV - Particle Vac is under the bench where the user works. The hose supplied is 2½" x 6 feet long and accords to the desired length. Other hose combinations are available for dual stations use. The hose may be shortened by removing the hose cuff from one end and carefully cutting with a sharp knife. The hose cuff threads onto the hose with a left-hand thread. Longer hoses and adapters are available from your dealer. We recommend that you try to keep the total length of hose less than 6 feet between the unit and the dust collection point. Longer hose will reduce suction. See the accessories section for collection device details.



PV - PARTICLE VAC 120V

MAINTENANCE

1. **Filter Bag Replacement** - When a noticeable drop in suction occurs in the unit or it shuts down, or the filter bag is two thirds full, it is time to replace the filter bag. **DO NOT** attempt to clean out the filter bag. Replace with a new Static Clean filter bag. To remove the filter bag remove the two thumb screws on the front of the unit and remove the front cover plate exposing the filter bag. Remove the used filter bag by sliding it off the inlet tube. The front of the cardboard reinforcement may need to be tilted downward slightly to remove the bag easily. Check the inside of the filter bag compartment. If dust is present please clean the compartment. Cause for residual dust may be due to improper installation. Vacuuming the excess dust will increase the life of the unit. Changing the filter bag regularly will save wear- and- tear on the motor. Re-order **P/N** PV-F3 (3-pack)
CAUTION: Operating the unit with a plugged filter bag or without one will cause permanent damage to the motor.
2. **Installing a new filter bag** - Slip the cardboard reinforcement, with rubber seal, over the inlet tube. You may need to tilt the front of the cardboard downward and slip back edge up past the tube end, then rotate upward over the tube. Carefully tuck the edges of the filter bag into the filter compartment. Replace the cover plate and gently tighten the thumb screws. Only gentle pressure need be used to make the gasket seal; the vacuum pressure will draw cover tight.
3. **Circuit Breaker** - The unit is protected by a circuit breaker on the right side of the unit. In the unlikely event there is an overload condition the breaker may trip. If this happens reset the breaker by pushing on the white button until it clicks into place.
4. **Motor Protection** - If the motor becomes too hot it will automatically shutoff to prevent damage. To reset the thermal gauge, turn off or unplug the unit and allow the motor to cool down. Once it has cooled you may turn it back on and continue use.
5. **Motor Brushes** - This long life motor does not have replaceable brushes. Replacement motors can be ordered as **P/N** PV-M.

REPLACEMENT PARTS

The following items are offered to enhance the usage of your quality Static Clean unit. These items can be order through your supplier using the following part numbers. Please feel free to contact Static Clean Mfg. Co. with questions regarding our products.

Fig. #	Description	Part Number
1	Red Dot Motor	PV-M
2	Motor Mount	2921
3	Gold Motor Clip	3273
4	Replacement Filter Bag 3-pack Replacement Filter Bag 5-pack	VMC-A400-3 VMC-A400-5
5	Front Cover Thumbscrew	1449
6	Remote Plug	1427
7	Power Switch ON/OFF	2904
Not Shown	Protective Switch Cover	1003B
8	Power Connector	3010
9	Rotary Switch Knob	1471
10	Rotary Switch	3019
11	Transformer	1419
12	Circuit Breaker, 15Amp	2869
13	Back Cover Screw 6-32 X 3/8" FHSMS	1448A
Not Shown	Power Cord	1422

